


Scope of delivery		Safety of lithium batteries		Symbols and warning signs		Technical data	
EN		EN		EN		EN	
Safety notes for lithium batteries		Symbols for warning notes		Name and standards		Flow message	
Fire fighting		Symbols for notes marking					

1 x connection cable kit 1 x connection cable (depending on device variant)	specified by the manufacturer. RoHS compliant	defined by European Directive 2012/19/EU (WEEE) and must not be disposed of as household waste.	parameters for SUPPLY FLOW set in the factory	Electromagnetic compatibility Interference resistance and emitted interference <table border="1"> <thead> <tr> <th>Length</th> <th>15 mm</th> <th>15 mm</th> <th>20 mm</th> <th>20 mm</th> <th>25 mm</th> <th>25 mm</th> <th>25 mm</th> <th>25 mm</th> <th>40 mm</th> <th>40 mm</th> <th>300 mm</th> </tr> </thead> <tbody> <tr> <td></td> <td>110 mm</td> <td>110 mm</td> <td>130 mm</td> <td>130 mm</td> <td>150 mm</td> <td>260 mm</td> <td>150 mm</td> <td>260 mm</td> <td>200 mm</td> <td>200 mm</td> <td>300 mm</td> </tr> </tbody> </table>	Length	15 mm	15 mm	20 mm	20 mm	25 mm	25 mm	25 mm	25 mm	40 mm	40 mm	300 mm		110 mm	110 mm	130 mm	130 mm	150 mm	260 mm	150 mm	260 mm	200 mm	200 mm	300 mm	<table border="1"> <thead> <tr> <th></th> <th>M-Bus</th> <th>Pulse inputs</th> </tr> </thead> <tbody> <tr> <td>1 length</td> <td>2 m</td> <td>1 m</td> </tr> </tbody> </table>		M-Bus	Pulse inputs	1 length	2 m	1 m
Length	15 mm	15 mm	20 mm	20 mm	25 mm	25 mm	25 mm	25 mm	40 mm	40 mm	300 mm																								
	110 mm	110 mm	130 mm	130 mm	150 mm	260 mm	150 mm	260 mm	200 mm	200 mm	300 mm																								
	M-Bus	Pulse inputs																																	
1 length	2 m	1 m																																	

[illegible]

Improper handling and excessively forceful tightening of threaded fittings can cause leaks. Observe the maximum torque stated in the manual.	Alternating or repeated displays.	The installed meter is a pressurized component. There is a risk of scalding by hot water.	Cable length (calculator unit wall-mounted installation): 80 cm Standard 1,5 m Optional 3,0 m	Cable length: Standard 1,5 m Optional 3,0 m	(1) optionally available (2) Careful formation in fast flowing liquids
---	--	--	--	--	---

EN	Installation variant ball valve	EN	Installation variants calculator unit	EN	Temperature sensors - immersion sleeves	Mounting - direct and indirect immersion		EN	Wall mounting of detachable calculator unit
-----------	---------------------------------	-----------	---------------------------------------	-----------	---	--	---	-----------	---

1. You can loosen the clip adapter from the flow sensor at any time by

(3) Clip adapter (detachable for variants up to 2.5 m³/h)

(5) Flow sensor Pos. B

(a) Insert the sensor into the immersion sleeve.

(b) The sensor is fully seated in the immersion sleeve.

(c) The immersion sleeve is closed.

(d) The immersion sleeve is secured with a screw fitting.

(e) The immersion sleeve is tightened.

(f) The immersion sleeve is fully secured.

(g) The final assembly of the immersion sleeve.

Note national and country-specific regulations

(a) The ball valve screw fitting is flush to the ball valve.

(b) Do not use the ball valve screw fitting to flush to the ball valve.

(c) When the temperature sensor is installed in immersion sleeves the type of

(1) Insert new seals

(2) Mount new meter

(1) Insert the "small" tab of the clip adapter into the slot on the flow meter. The flow meter sensor can be turned through 180°. This is useful for measuring in the opposite direction.

(2) Then click the "large" tab in place behind the direction of flow arrow on the

Indirectly immersed		the calculator unit.			calculator unit. On-site repair work is <u>not</u> possible.		calculator unit. On-site repair work is <u>not</u> possible.		calculator unit. On-site repair work is <u>not</u> possible.
---------------------	---	----------------------	---	---	--	---	--	---	--

[illegible]

Diagram illustrating the components and functions of the device interface:

- (1) Power supply connection
- (2) RS-485 connection
- (3) RS-485 connection
- (4) Interface cover
- (5) Available in all device versions.
- (6) Can be hidden individually.
- (7) Operating time
- (8) Device must be replaced, expired.
- (9) Error code
- (10) Error code
- (11) Error code
- (12) Error code
- (13) Error code
- (14) Error code
- (15) Error code
- (16) Error code
- (17) Error code
- (18) Error code
- (19) Error code
- (20) Error code
- (21) Error code
- (22) Error code
- (23) Error code
- (24) Error code
- (25) Error code
- (26) Error code
- (27) Error code
- (28) Error code
- (29) Error code
- (30) Error code
- (31) Error code
- (32) Error code
- (33) Error code
- (34) Error code
- (35) Error code
- (36) Error code
- (37) Error code
- (38) Error code
- (39) Error code
- (40) Error code
- (41) Error code
- (42) Error code
- (43) Error code
- (44) Error code
- (45) Error code
- (46) Error code
- (47) Error code
- (48) Error code
- (49) Error code
- (50) Error code
- (51) Error code
- (52) Error code
- (53) Error code
- (54) Error code
- (55) Error code
- (56) Error code
- (57) Error code
- (58) Error code
- (59) Error code
- (60) Error code
- (61) Error code
- (62) Error code
- (63) Error code
- (64) Error code
- (65) Error code
- (66) Error code
- (67) Error code
- (68) Error code
- (69) Error code
- (70) Error code
- (71) Error code
- (72) Error code
- (73) Error code
- (74) Error code
- (75) Error code
- (76) Error code
- (77) Error code
- (78) Error code
- (79) Error code
- (80) Error code
- (81) Error code
- (82) Error code
- (83) Error code
- (84) Error code
- (85) Error code
- (86) Error code
- (87) Error code
- (88) Error code
- (89) Error code
- (90) Error code
- (91) Error code
- (92) Error code
- (93) Error code
- (94) Error code
- (95) Error code
- (96) Error code
- (97) Error code
- (98) Error code
- (99) Error code
- (100) Error code

M-Bus connection									
	Current value heat 	places appear (depending on the device configuration). • Air in the meas- • Bled the pipe system		Consumption value: current 	Pulse input 1 	Current capacity 	no meter	Display level 1 5... Month's values heat 	Display level

• Use high-quality spring-loaded clamps or crimp connections according to the

• Avoid shutdowns of the M-Bus.
 • Avoid short circuits on the M-Bus line during service work and subsequent installation.

everything off 0.5 sec.

The "Current value to the level"

You can choose the level you

Displayed data applies to:

- Heat = Pulse input 1
- Imp1 = Pulse input 1

 * Only available for device version with pulse input.
 • Can be hidden individually.

Display level

Pulse value
 Impulse rate
 monthly value
 Heat

All logical devices (heat and cold meters, water meters/hold, ...) are identified in the M-Bus system with a secondary or primary address. 0.5 sec. longer than 2 seconds. M (Memory) = Value on a monthly or due date. - Can be hidden individually.	Annual consumption 2536.143 m³ 31.12.21 Heat	version firmware version monthly value Heat 31.12.21 2536.143	Display level 68 Pul2
---	--	---	-------------------------------------

Alternatively, a 3-digit primary address can be assigned for each logical device.

The primary addresses (1-250) are parameterised on the meter in the display level 4 (2om).

21	22	23	24	25	26	27	28
		1) Communication is currently active.	1) Display depends on device configuration		2) Display depends on device configuration		

EN Parameter setting – key assignment	EN Setting parameters for due date	EN Display units and levels	EN Parameter setting pulse inputs	EN Continuation: Parameter settings pulse input 1 (lmp1) for external consumption meter (Part 1)
EN Navigating within the levels			EN Parameter settings pulse input 1 (lmp1) for external consumption meter (Part 2)	EN Continuation: Parameter settings pulse input 1 (lmp1) (part 2)

[illegible]

Adjustment options: Pulse valence, units, filters

Parameter setting mode PIN
 To be able to set the parameter settings mode, you have to be in the parameter setting mode. Press the <V> key several times briefly until the value 2.5 litre / kWh pulse without unit appears on the display. Press the <H> and <V> keys to enter the 8-digit meter number. Press the <V> key to parameterize pulse input 2 (imp2) in the same way as pulse input 1 (imp1), briefly press the <V> key.

The default standard PIN is printed on the device packaging. Once the PIN has been

Activating parameter setting mode (only available on level L3 and L4) **Setting parameters for installation location, display units and levels**

6. Press the <V> key briefly again to show the required level.

When resetting the meter number, all meter pulses listed up to that point are reset and permanently deleted!

2. Use the <V> key to display the respective value (e.g.: date).
3. Press the <V> key briefly until the display for levels, position location and direction is displayed.
4. Confirm all settings using the key combination <H> <V> <V>.

the display for password entry appears.	3. The installation location can only be changed up to a cumulated flow of 50 litres. The example level displays	4. The temperature can be set in the primary position appears.	5. The temperature can be set in the primary position appears.
--	---	---	---

5 Press the < H > key to jump to the next segment block.

Confirm the setting by pressing keys <H> <V> simultaneously. If the correct appearance has been entered, the location appears on the right on the display.

4 To parameterise further primary addresses, press the **PRG** key.

[illegible]